


NOTES:

1. SWITCH SOCKET OUTLET TO BE MOUNTED AT A MINIMUM HEIGHT OF 150mm ABOVE THE KITCHEN WORKTOP.
2. NO SWITCH SOCKET OUTLET OR SWITCH TO BE MOUNTED AT THE 300mm x 300mm WALL SPACE AT BOTH SIDES OF THE HOB AS SHOWN ABOVE.
3. UNSWITCHED FUSED CONNECTION UNITS FOR GAS HOB IGNITOR AND OVEN TO BE INSTALLED IN A SEPERATE COMPARTMENT, SEGREGATED FROM GAS PIPE CONNECTION TO THE HOB.

Drawing Title

TYPICAL INSTALLATION DETAIL OF ELECTRICAL OUTLET FOR COOKER HOOD, HOB & OVEN

Alpha Consulting Engineers Pte Ltd	Drawing No. SE(EI) – 20	Rev. D